



### 6.5 Operation Graphics of ESM-3712-HCN Temperature Controller

1-If Operating Type Parameter Value  $[H[S]] = 1$  (Cooling),  
Switch On Delay After Power On Parameter Value  $[P_{OS}] = 1$ ,  
Compressor Stop/Start Time Delay Parameter Value  $[S_{PD}] = 1$  and  
Compressor Start/Start Time Delay Parameter Value  $[S_{TD}] = 1$ ;



2-If Operating Type Parameter Value  $[H[S]] = 0$  (Heating),




In ON/OFF control algorithm, temperature value is tried to keep equal to set value by opening or closing the last control element. ON/OFF controlled system, temperature value oscillates continuously. Temperature value's oscillation period or amplitude around set value changes according to controlled system. For reducing oscillation period of temperature value, a threshold zone is formed below or around set value and this zone is named hysteresis. Action of control output is described with figures above.


### 6.6 Failure Messages in ESM-3712-HCN Temperature Controller

$[S_{bF}]$  Screen Blinking  
Sensor failure. Sensor connection is wrong or there is no sensor connection. If buzzer function selection parameter  $[S_{UF}]$  is 2, internal buzzer starts to operate.

### 6.7 Entering To The Programming Mode, Changing and Saving Parameter




When SET button is pressed for 5 seconds, "PR" led starts to blink. If programming mode entering password is different from 0, programming mode entering screen  $[P_{FR}]$  will be observed.  
**Note1:** If programming mode accessing password is 0, Temperature Unit screen is observed instead of programming screen  $[P_{FR}]$ .  
Press SET button for accessing to the password entering screen.




Enter programming mode accessing password with increment and decrement buttons.  
Press SET/OK button for entering the password.

**Note2:** If programming mode accessing password is 0, only three parameters are accessible, and the parameter values can be changed.



Press SET button for accessing to the parameter value. Press increment button for accessing to the next parameter, press decrement button for accessing to the previous parameter.  
Change the value with increment and decrement buttons.



Press set button for saving the parameter.  
Press increment button for accessing to the next parameter, press decrement button for accessing to the previous parameter.

If no operation is performed in programming mode for 20 seconds, device turns to main operation screen automatically.



ESM-3712-HCN 77x35 DIN Size Temperature Controller



### ESM-3712-HCN 77 x 35 DIN Size Digital ON / OFF Temperature Controller (ALARM+SET)

- 4 Digits Display
- NTC Input or PTC Input or J Type thermocouple Input or, K Type thermocouple Input or,
- 2-Wire PT-100 Input or,
- 2-Wire PT-1000 Input (Must be determined in order.)
- ON/OFF temperature control
- 2 output for compressor and alarm controls
- Selectable heating or cooling function
- Selection of operation with hysteresis
- Adjustable temperature offset
- Process Set value and Alarm Set value low limit and set value high limit boundaries
- Operation selection of compressor operates continuously, stops or operates periodically in case of sensor defect
- Compressor protection delays
- Alarm parameters
- Adjustable Alarm Set Value from front panel
- Adjustable internal buzzer according to Sensor prob defect and Alarm status
- Password protection for programming section
- Installing parameters using Prokey
- Remote access, data collecting and controlling with Modbus RTU
- Having CE mark according to European Norms

Instruction Manual. ENG ESM-3712-HCN 01 V03 10/19

### 1.Preface


ESM-3712HCN series temperature controllers are designed for measuring and controlling temperature. They can be used in many applications with their On / Off control form, heating and cooling control form and easy-use properties. Some application fields which they are used are below:

Application Fields	Applications
Glass	Heating
Food	Baking Ovens
Plastic	Incubators
Petro-Chemistry	Storages
Textile,	Automotive Air Conditioning
Machine Production Industries Etc...	Etc...

### 1.1 Environmental Ratings

- Operating Temperature : 0 to 50 °C
- Max. Operating Humidity : 90% Rh (non-condensing)
- Altitude : Up to 2000 m.
- Forbidden Conditions: Corrosive atmosphere, Explosive atmosphere, Home applications (The unit is only for industrial applications)

### 1.2 General Specifications




### 7. Specifications

- Device Type** : Temperature Controller
- Housing&Mounting** : 76mm x 34.5mm x 71mm plastic housing for panel Mounting. Panel cut-out is 71x29mm.
- Protection Class** : NEMA 4X (Ip65 at front, Ip20 at rear).
- Weight** : Approximately 0.20 Kg.
- Environmental Ratings** : Standard, indoor at an altitude of less than 2000 meters with none condensing humidity.
- Storage / Operating Temperature** : -40 °C to +80 °C / -30 °C to +80 °C
- Storage / Operating Humidity** : 90 % max. (None condensing)
- Installation** : Fixed installation
- Overvoltage Category** : II.
- Pollution Degree** : II, office or workplace, none conductive pollution
- Operating Conditions** : Continuous
- Supply Voltage and Power** : 230V~ (±15%) 50/60Hz - 1.5VA, 115V~ (±15%) 50/60Hz - 1.5VA, 24V~ (±15%) 50/60Hz - 1.5VA, 24V~ (±15%) 50/60Hz - 1.5VA, 10 - 30V= 1.5W
- Temperature Sensor Input** : NTC, PTC, TC, RTD
- NTC input type** : NTC (10 k @25 °C)
- PTC input type** : PTC (1000 @25 °C)
- Thermocouple input type** : J, K (IEC584.1) (ITS 90)
- Thermoresistance input type** : PT-100, PT-1000 (IEC751) (ITS 90)
- Accuracy** : ± 1 % of full scale for thermoresistance
- Sensor Break Protection** : Upscale
- Sampling Cycle** : 3 samples per second
- Control Form** : ON / OFF
- Relay Outputs** : 16(8) A@250 V ~ for Resistive load (Compressor output) (Electrical life : 100.000 switching at full load) for Resistive load 5 A@250 V ~ (Alarm output)
- Display** : 14 mm Red 4 digits LED Display
- LED** : S (Green), P (Green), A (Green), °C (Yellow), °F (Yellow), Compressor Output (Red), Alarm Output (Red)
- Internal Buzzer** : 83dB
- Approvals** : ERIC CE

### 8.Optional Accessories

- 1.RS-485 Module
- 2.PROKEY Programming Module



~ Vac,  
~ Vdc  
~ Vdc or Vac can be applied

The device is programmed/Upload or Download) by using the parameters.

### 9.Ordering Information

ESM-3712HCN (77x35 DIN Sizes)	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	Z
	0	1	00	1	2	0	0																	
<b>A Supply Voltage</b>																								
2	24V~ (±15%) 50/60Hz - 1.5VA																							
3	24V~ (±15%) 50/60Hz - 1.5VA																							
4	115V~ (±15%) 50/60Hz - 1.5VA																							
5	230V~ (±15%) 50/60Hz - 1.5VA																							
8	10 - 30 V =																							
<b>BC Input Type</b>																								
05	J Fe CuNi IEC584.1(ITS90) 0°C/32°F : 800°C/1472°F																							
10	K NiCr Ni IEC584.1(ITS90) 0°C/32°F : 999°C/1830°F																							
11	PT 100, IEC751(ITS90) -50°C/-58°F : 400°C/752°F																							
09	PT 100, IEC751(ITS90) -19.9°C/-4°F : 99.9°C/212°F																							
14	PT 1000, IEC751(ITS90) -50°C/-58°F : 400°C/752°F																							
13	PT 1000, IEC751(ITS90) -19.9°C/-4°F : 99.9°C/212°F																							
12	PTC (Not-1) -50°C/-58°F : 150°C/302°F																							
18	NTC (Not-1) -50°C/-58°F : 100°C/212°F																							
<b>E Compressor Output</b>																								
1	Relay Output (16(8) A@250 V ~,at resistive Load, NO + NC )																							
<b>FG Alarm Output</b>																								
01	Relay Output (5 A@250 V ~,at resistive Load, 1 NO )																							
<b>V Temp. Sensor which is given with ESM-3712HCN</b>																								
0	None																							
1	PTC-M6L40.K1.5 (PTC Air Probe 1.5 mt Silicon Cable)																							
2	PTCS-M6L30.K1.5.1/8" (PTC Liquid Probe 1.5 mt Silicon Cable)																							
3	NTC-M5L20.K1.5 (NTC Sensor, thermoplastic moulded with 1.5 m cable for cooling application)																							
4	NTC-M6L50.K1.5 (NTC Sensor, stainless steel housing with 1.5 m cable for cooling application)																							
9	Customer																							

All order information of ESM-3712-HCN Temperature Controller are given on the table at above. User may form appropriate device configuration from information and codes that at the table and convert it to the ordering codes. Firstly, supply voltage then other specifications must be determined. Please fill the order code blanks according to your needs.

Please contact us, if your needs are out of the standards.  
**Note-1:** If input type is selected PTC or NTC (BC= 12, 18), Temperature sensor is given with the device. For this reason, if input type is selected as PTC, sensor type (V= 0, 1 or 2) or if input type is selected as NTC, sensor type (V= 0, 3 or 4) must be declared in ordering information.

Thank you very much for your preference to use Emko Elektronik products, please visit our Your Technology Partner Web page to download detailed user manual. [www.emkoelektronik.com.tr](http://www.emkoelektronik.com.tr)

### 1.3 Installation

A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.

If there is danger of serious accident resulting from a failure or defect in this unit, power off the system and separate the electrical connection of the device from the system.

The unit is normally supplied without a power supply switch or a fuse. Use power switch and fuse as required.

Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

Never attempt to disassemble, modify or repair this unit. Tampering with the unit may result in malfunction, electric shock or fire.

Do not use the unit in combustible or explosive gaseous atmospheres.

During putting equipment in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you must be careful.

Montage of the product on a system must be done with it's fixing clamps. Do not do the montage of the device with inappropriate fixing clamp. Be sure that device will not fall while doing the montage.

It is your responsibility if this equipment is used in a manner not specified in this instruction manual.

### 1.4 Warranty

EMKO Elektronik warrants that the equipment delivered is free from defects in material and workmanship. This warranty is provided for a period of two years. The warranty period starts from the delivery date. This warranty is in force if duty and responsibilities which are determined in warranty document and instruction manual performs by the customer completely.


### 1.5 Maintenance

Repairs should only be performed by trained and specialized personnel. Cut power to the device before accessing internal parts. Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.


### 1.6 Manufacturer Company

**Manufacturer Information:**  
Emko Elektronik Sanayi ve Ticaret A.Ş.  
Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369 BURSA/TURKEY  
Phone : +90 224 261 1900  
Fax : +90 224 261 1912  
**Repair and maintenance service information:**  
Emko Elektronik Sanayi ve Ticaret A.Ş.  
Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369 BURSA/TURKEY  
Phone : +90 224 261 1900  
Fax : +90 224 261 1912


### 2. General Description




### 2.1 Front View and Dimensions of ESM-3712-HCN Temperature Controller



### 2.2 Panel Cut-Out




### 2.3 Panel Mounting



1-Before mounting the device in your panel, make sure that the cut-out is of the right size.  
2-Insert the device through the cut-out. If the mounting clamps are on the unit, put them before inserting the unit to the panel.  
3- Insert the mounting clamps to the fixing sockets that located left and right sides of device and make the unit completely immobile within the panel

### 2.4 Removing from the Panel



1-Pull mounting clamps from left and right fixing sockets.  
2-Pull the unit through the front side of the panel.  
Before starting to remove the unit from panel, power off the unit and the related system.

### 3. Using Prokey

TO USE PROKEY, VALUE OF THE PrC PARAMETER MUST BE '0'. IF PrC=1 AND ▼ BUTTON IS PRESSED [PrC] MESSAGE WILL BE SHOWN. 10s. LATER DEVICE TURNS BACK TO THE MAIN OPERATION SCREEN OR YOU CAN PRESS SET BUTTON TO TURN BACK TO MAIN OPERATION SCREEN.

#### DOWNLOADING FROM DEVICE TO PROKEY

- The device is programmed by using the parameters.
- Energize the device then put in PROKEY and press ▼ button. [PrC] Message is shown on the display. When the loading has finished, [End] message is shown.
- Press any button to turn back to main operation screen.
- Remove the PROKEY.


NOTE: [PrC] message is shown when an error occurs while programming. If you want to reload, put in PROKEY and press ▼ button. If you want to quit, remove PROKEY and press ▼ button. The device will turn back to main operation screen.

#### DOWNLOADING FROM PROKEY TO DEVICE

- Switch off the device.
- Put in PROKEY then energize the device.
- When the device is energized, the parameter values in PROKEY, start downloading to the device automatically. At first, [PrC] message is shown on the display, when loading has finished, [End] message is shown.
- After 10 seconds device starts to operate with new parameter values.
- Remove the PROKEY.


NOTE: [PrC] message is shown when an error occurs while programming. If you want to reload, switch off the device and put in PROKEY then energize the device. If you want to quit remove PROKEY and press ▼ button. The device will turn back to main operation screen.

### 4. Electrical Wiring Diagram




#### 4.1 Supply Voltage Input Connection of the Device

**Power Supply Connection**  
Make sure that the power supply voltage is the same indicated on the instrument. Switch on the power supply only after that all the electrical connections have been completed. Supply voltage range must be determined in order. While installing the unit, supply voltage range must be controlled and appropriate supply voltage must be applied to the unit.



NOTE-1 : External fuse is recommended.

#### 4.2 Device Label and Connection Diagram




### 6.2 Programming Mode Parameter List

- C-F** Temperature Unit Selection Parameter (Default = 0) MODBUS ADDRESS : 40002  
0 °C selected.  
1 °F selected.
- Pnt** Decimal Separator Enabling Parameter (Default = 0) MODBUS ADDRESS:40003  
0 Disable.  
1 Enable.
- HSt** Hysteresis Parameter for Compressor Output (Default = 1) MODBUS ADDRESS:40004  
From 1 to 20°C for NTC (-50°C, 100°C), PTC (-50°C, 150°C), J Type TC (0°C, 800°C), K Type TC (0°C, 1000°C), PT-100 Type (-50°C, 400°C), PT-1000 Type (-50°C, 400°C), PT-100 Type (-20°C, 100°C),  
From 1 to 36°F for NTC (-58°F, 212°F), PTC (-58°F, 302°F), J Type TC (32°F, 1472°F), K Type TC (32°F, 1830°F), PT-100 Type (-58°F, 752°F), PT-1000 Type (-58°F, 752°F), PT-100 Type (-4°F, 212°F)  
From 0.1 to 10.0°C for NTC (-50.0°C, 100.0°C), PTC (-50.0°C, 150.0°C), PT-100 (-19.9°C, 99.9°C),  
From 0.1 to 18.0°F for NTC (-58.0°F, 212.0°F), PTC (-58.0°F, 302.0°F), PT-100 (-4.0°F, 212.0°F),  
In ON/OFF control algorithm, temperature value is tried to keep equal to set value by opening or closing the last control element. ON/OFF controlled system, temperature value oscillates continuously. Temperature value's oscillation period or amplitude around set value changes according to controlled system. For reducing oscillation period of temperature value, a threshold zone is formed below or around set value and this zone is named hysteresis.
- SuL** Minimum Temperature Set Value Parameter (Default = Minimum Value of Device Scale) MODBUS ADDRESS:40005  
Temperature set value can not be lower than this value. This parameter value can be adjusted from minimum value of device scale to maximum temperature set value parameter [SuH]
- SuH** Maximum Temperature Set Value Parameter (Default = Maximum Value of Device Scale) MODBUS ADDRESS:40006  
Temperature set value can not be bigger than this value. This parameter value can be adjusted from minimum temperature set value parameter [SuL] to maximum value of the device scale
- oFt** Sensor Offset Parameter (Default = 0) MODBUS ADDRESS:40007  
From -20 to 20 °C for NTC (-50°C, 100°C), PTC (-50°C, 150°C), J Type TC (0°C, 800°C), K Type TC (0°C, 1000°C), PT-100 (-50°C, 400°C), PT-1000 (-50°C, 150°C), PT-100 (-20°C, 100°C),  
From -36 to 36 °F for NTC (-58°F, 212°F), PTC (-58°F, 302°F), J Type TC (32°F, 1472°F), K Type TC (32°F, 1830°F), PT-100 (-58°F, 752°F), PT-1000 (-58°F, 752°F), PT-100 (-4°F, 212°F), PT-100 (-19.9°C, 99.9°C),  
From -18.0 to 18.0°F for NTC (-58.0°F, 212.0°F), PTC (-58.0°F, 302.0°F), PT-100 (-4.0°F, 212.0°F)
- HCS** Operating Type Parameter (Default = 0) MODBUS ADDRESS:40008  
If parameter value is '0' device skips to [RLS] parameter  
0 Heating  
1 Cooling
- Pos** Compressor Start Delay at Power On Parameter (Default = 0) MODBUS ADDRESS:40009  
When power is first applied to the device, compressor is on when this time delay is expired. It can be adjusted from 0 to 20 minutes.

- buf** Buzzer Function Selection Parameter (Default = 0) MODBUS ADDRESS:40023  
0 Buzzer is inactive.  
1 Buzzer is active if an alarm occurs.  
2 Buzzer is active during sensor failures.  
3 Buzzer is active during alarm or sensor failures.
- bon** Buzzer is active during this time (Default = [PrC]) MODBUS ADDRESS:40024  
If buzzer function selection parameter value [buf]=0, this parameter can not be observed. Buzzer stays active during this time. It can be adjusted from 1 to 99 minutes. When this parameter is 1, if decrement button is pressed, [PrC] is observed. In this condition buzzer is active till buzzer silence button is pressed.
- PrC** Communication Mode Selection Parameter (Default = 0) MODBUS ADDRESS:40025  
0 PROKEY communication selected.  
1 RS 485 communication selected.
- SAD** Slave ID Parameter (Default = 1) MODBUS ADDRESS:40026  
Device communication address parameter (1 to 247).
- AEOn** Manual Alarm Output Active Parameters (Default = 0) MODBUS ADDRESS:40027  
0 Manual Alarm output passive.  
1 Manual Alarm output active
- PAS** Programming Section Accessing Password (Default = 0) MODBUS ADDRESS:40028  
It is used for accessing to the programming section. It can be adjusted from 0 to 9999. If it is selected 0, password will not be asked.

- 6.3 Modbus Addresses of Device Status Parameters (Read Input Register)**
- MODBUS ADRES:30001 Temperature Value
- MODBUS ADRES:30002 Led Status : 0.Bit °C Led, 6.bit Compressor Led, 7.bit Alarm Led, 13.bit Program Led, 14.bit Set Led
- MODBUS ADRES:30003 Device Status : 0.Bit Alarm Status, 2.Bit Buzzer Status, 3.Bit Sensor Break Status
- MODBUS ADRES:30004 Output Status : 0.Bit Compressor Output, 1.Bit Alarm Output
- MODBUS ADRES:30005 Device Type and Device Version

### 5.Front Panel Definition and Accessing to the Menus




#### BUTTON DEFINITIONS

- Increment Button :**  
\*\* It is used to increase the value in the Set screen and Programming mode.  
\*\* In the main operation screen: After pressing this button for 5 seconds, alarm output will be Active manually during pressing button. Alarm output will be passive after release the button.
- Decrement, Silencing Buzzer and Downloading to Prokey Button :**  
\*\* It is used to decrease the value in the Set screen and Programming mode.  
\*\* It is used to silence the buzzer.  
\*\* If PrC=0, it is used to download from device to prokey.
- Set Button :**  
\*\* In the main operation screen; if this button pressed, set value will be displayed. Value can be changed using increment and decrement buttons. When Set button pressed again, value is saved and returns back to main operating screen.  
\*\* To access the programming screen; in the main operation screen, press this button for 5 seconds.  
\*\* It is used to saving value in the Set screen and programming screen.
- Alarm Set Button :**  
\*\* In the main operation screen; if this button is pressed, Alarm set value will be displayed. Value can be changed using increment and decrement buttons. When Set button is pressed again, value is saved and returns back to main operating screen.


- LED DEFINITIONS**
- 5.Cooling led :**  
\*\* This led indicates that cooling control is selected and process output relay is active. If any of compressor protection time active, this led blinks.
- 6.Heating led :**  
\*\* This led indicates that heating control is selected and process output relay is active.
- 7.Alarm led :**  
\*\* It is active in all alarm status.
- 8.Celcius led :**  
\*\* Indicates that device is in °C mode.
- 9.Fahrenheit led :**  
\*\* Indicates that device is in °F mode.
- 10.Alarm Set led :**  
\*\* It is active when alarm statuses.
- 11.Set led :**  
\*\* Indicates that device is in Set value changing mode.
- 12.Program led :**  
\*\* Blinks in programming mode.

### 6. Changing and Saving Temperature Set Value



Temperature set value parameter (Default=30) MODBUS ADDRESS:40001  
Temperature set value, can be programmed between minimum temperature set value [SuL] and maximum temperature set value [SuH].

### 6.1 Changing and Saving Alarm Set Value



If no operation is performed in Alarm set value changing mode and process set value changing mode for 20 seconds, device turns to main operation screen automatically.

- SPd** Compressor Stop-Start Delay Parameter (Default = 0) MODBUS ADRES:40010  
When compressor is inactive, this time delay must be expired for activation of the compressor. It can be adjusted from 0 to 20 minutes.
- Std** Compressor Start-Start Delay Parameter (Default = 0) MODBUS ADRES:40011  
This time delay must be expired between two activation of the compressor. It can be adjusted from 0 to 20 minutes.
- PdF** Sensor Defect Parameter (Default = 0) MODBUS ADDRESS:40012  
0 Compressor is OFF in case of sensor defect.  
1 Compressor is ON in case of sensor defect.  
2 Compressor operates periodically according to [Pon] and [Pof] Time periods in case of sensor defect.
- Pon** Compressor is active during this time period in case of probe defect (Default = 0) MODBUS ADDRESS:40013  
If probe defect parameter [PdF] is 2, then this parameter is observed. It can be adjusted from 0 to 99 minutes.
- Pof** Compressor is inactive during this time period in case of probe defect (Default = 0) MODBUS ADDRESS:40014  
If probe defect parameter [PdF] is 2, then this parameter is observed. It can be adjusted from 0 to 99 minutes.
- RLS** Alarm Type Selection Parameter (Default = 2) MODBUS ADRES:40015  
0 Sensor Break Alarm  
1 Process High Alarm  
2 Process Low Alarm  
3 Deviation High Alarm  
4 Deviation Low Alarm  
5 Deviation Band Alarm  
6 Deviation Range Alarm
- RLl** Alarm Set Value Low Limit Parameter (Default = Minimum Value of Device Scale) MODBUS ADDRESS:40016  
Alarm set value can not be lower than this value. This parameter value can be adjusted from minimum process set value parameter to alarm set value high limit parameter value.
- RuL** Alarm Set Value High Limit Parameter (Default = Maximum Value of Device Scale) MODBUS ADDRESS:40017  
Alarm set value can not be greater than this value. This parameter value can be adjusted from alarm set value low limit parameter value to maximum process set value parameter.
- Ron** Alarm On Delay Time Parameter (Default = 0) MODBUS ADDRESS:40018  
It can be adjusted from 0 to 999 seconds.
- RoF** Alarm Off Delay Time Parameter (Default = 0) MODBUS ADDRESS:40019  
Alarm set value can not be adjusted from 0 to 99 minutes. When this parameter is 99, if increment button is pressed, [RLH] is observed and alarm latching output is selected. To make the alarm latching output passive, decrement button must be pressed in main operation screen.
- Rpd** Alarm Delay Parameter After Power On (Default = 0) MODBUS ADDRESS:40020  
This parameter defines the delay for the alarm is being active after power on. It can be adjusted from 0 to 99 minutes.
- RLS** Alarm Set Value Parameter (Default = 20) MODBUS ADDRESS:40021  
Alarm output is controlled according to this value. For alarm type selection parameter [RLS]=1 or 2, this parameter value is can be adjusted from alarm set value low limit [RLl] parameter to alarm set value high limit [RuL] parameter; for alarm type selection parameter [RLS]=3, 4, 5 or 6 this parameter value is can be adjusted from 0 to alarm set value high limit [RuL] parameter.
- RLH** Alarm Hysteresis Parameter (Default = 0) MODBUS ADDRESS:40022  
Alarm hysteresis value. This parameter is can be adjusted 0 to %50 of the device scale.

### 6.4 Operation Graphics of Alarm Output and Alarm Types

